CRICUT® SCORING TIP WITH HOUSING INSTRUCTIONS

Detailed instructions on how to use the Cricut® scoring tip with housing.

CRICUT®, CRICUT CREATE® & CRICUT EXPRESSION® MACHINES

- Insert the Tags, Bags, Boxes & More® 2 cartridge.
- Select the desired scoring lines.
- Replace the cutting blade and housing with the scoring tip and housing.
- Adjust the machine pressure, speed, and blade depth according to the material being used.
- Load Mat and press **CUT**!
- Once scoring is finished, **DO NOT** unload mat. Press **LOAD MAT** to return the machine to the starting position.
- Carefully remove the scoring tip and insert the cutting blade assembly.

  ***Note:** Moving the carriage will cause the score and cut lines to misalign.*
- Adjust the machine pressure, speed, and blade depth according to the material being cut.
- Select the coordinating image and press **CUT**!
- Once finished, unload mat, remove the images, and assemble according to directions shown in the Assembly Instructions handbook.

CRICUT EXPRESSION® 2 & CRICUT EXPRESSION® 2: 5TH ANNIVERSARY EDITION MACHINES

- Insert the Tags, Bags, Boxes & More® 2 cartridge.
- Select the desired scoring lines and then click the **HOME** button.
- Replace the cutting blade and housing with the scoring tip and housing.
- Select the Multi-tool feature in the Apply All settings menu.
- Select **LOAD MAT**.
- Select **CUT SETTINGS**.
- Select the scoring tip from the materials dropdown menu.

  ***Note:** Remember to add the scoring tip to the materials and tools. Refer to the Cricut Expression® 2 or Cricut Expression® 2: 5th Anniversary Edition user manual.*
- Adjust blade depth according to material being used. Select **CUT**!
- Once scoring is finished, **DO NOT** unload mat. Carefully remove the scoring tip and insert the Cricut® cutting blade assembly. Adjust the depth according to the material being used.

  ***Note:** Moving the carriage will cause the score and cut lines to misalign.*
- Click the **IMAGE GALLERY** button to return to the overlay view.
- Delete the scoring image.
- Select the coordinating image and then the **HOME** button.
- Select **CUT SETTINGS** and the correct material from the dropdown menu. Click **CUT**!
- Once finished, unload mat, remove the image, and assemble according to directions shown in the Assembly Instructions handbook.

Cricut